

**S-TYPE**

DATE 04/00

S417-01

**SERVICE****TECHNICAL BULLETIN****Daytime Running Lamps –  
Enable/Disable**MODEL 2000 MY-ON  
S-TYPE

VIN L00001-ON

**Issue:**

The daytime running lamps feature of S-TYPE vehicles may be enabled/disabled as a customer requested option, **except** in markets where daytime running lamps are either mandatory or prohibited. Daytime running lamps are permissible in the USA.

**Action:**

In markets where daytime running lamps are mandatory, ensure that this feature is ON. Should it be necessary to change the existing setting, the following PDU procedure should be followed:

1. Locate PDU disk **JTP 627/5** or later and load into **PDU**.
2. Highlight **DIAGNOSTICS**.
3. Enter **VIN**.
4. Enter **VEHICLE FEATURES**.
5. In the Main Menu, select **VEHICLE SET-UP**.
6. Select **VEHICLE CM SET-UP/CONFIGURATION**.
7. Initiate **MPA**.
8. Connect **PDU** and **MPA** to vehicle.
9. Select **DEALER OPTIONS**.

**⚠ Caution: North American Specification vehicles are not equipped with steering column locks. Ensure that NO is selected.**

10. Select **DAYLIGHT RUNNING LAMPS MODE**.
11. Then highlight the required mode to enable the feature or remove the highlight to disable the feature:  
**REST OF WORLD LAMPS ENABLE**  
**CANADIAN DAYLIGHT RUNNING LAMPS ENABLE**
12. When one of the above modes has been highlighted, press the check mark, then the PDU will confirm that it has been successfully programmed.

13. Check the function of the daytime running lights, by starting the engine and placing the selector lever in Reverse or Drive ranges. Daytime running lights will not function in Park or Neutral.

**Warranty Information:**

This Bulletin is issued for information only.